

SSA-599968: Denial of Service Vulnerability in Profinet Devices

Publication Date: 2021-07-13
Last Update: 2024-12-10
Current Version: V1.8
CVSS v3.1 Base Score: 7.5
CVSS v4.0 Base Score: 8.7

SUMMARY

A vulnerability in affected devices could allow an attacker to perform a denial of service attack if a large amount of Profinet Discovery and Configuration Protocol (DCP) reset packets is sent to the affected devices.

Siemens has released new versions for several affected products and recommends to update to the latest versions. Siemens recommends specific countermeasures for products where fixes are not, or not yet available.

AFFECTED PRODUCTS AND SOLUTION

Affected Product and Versions	Remediation
Development/Evaluation Kits for PROFINET IO: DK Standard Ethernet Controller: All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
Development/Evaluation Kits for PROFINET IO: EK-ERTEC 200: All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
Development/Evaluation Kits for PROFINET IO: EK-ERTEC 200P: All versions < V4.7 affected by CVE-2020-28400	Update to V4.7 or later version https://support.industry.siemens.com/cs/ww/en/view/109784253/ See further recommendations from section Workarounds and Mitigations
SCALANCE M-800 family (incl. S615, MUM-800 and RM1224):	Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations
RUGGEDCOM RM1224 family (6GK6108-4AM00):	Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations

<p>RUGGEDCOM RM1224 LTE(4G) EU (6GK6108-4AM00-2BA2):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>RUGGEDCOM RM1224 LTE(4G) NAM (6GK6108-4AM00-2DA2):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE M-800 family:</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE M804PB (6GK5804-0AP00-2AA2):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE M812-1 ADSL-Router family:</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE M812-1 ADSL-Router (6GK5812-1BA00-2AA2):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE M812-1 ADSL-Router (6GK5812-1AA00-2AA2):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE M816-1 ADSL-Router family:</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE M816-1 ADSL-Router (6GK5816-1BA00-2AA2): All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE M816-1 ADSL-Router (6GK5816-1AA00-2AA2): All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE M826-2 SHDSL-Router (6GK5826-2AB00-2AB2): All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE M874-2 (6GK5874-2AA00-2AA2): All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE M874-3 (6GK5874-3AA00-2AA2): All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE M874-3 3G-Router (CN) (6GK5874-3AA00-2FA2): All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE M876-3 (6GK5876-3AA02-2BA2): All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE M876-3 (ROK) (6GK5876-3AA02-2EA2): All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE M876-4 (6GK5876-4AA10-2BA2):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE M876-4 (EU) (6GK5876-4AA00-2BA2):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE M876-4 (NAM) (6GK5876-4AA00-2DA2):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE MUM-800 family:</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE MUM853-1 (A1) (6GK5853-2EA10-2AA1):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE MUM853-1 (B1) (6GK5853-2EA10-2BA1):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE MUM853-1 (EU) (6GK5853-2EA00-2DA1):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE MUM856-1 (A1) (6GK5856-2EA10-3AA1):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE MUM856-1 (B1) (6GK5856-2EA10-3BA1):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE MUM856-1 (CN) (6GK5856-2EA00-3FA1):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE MUM856-1 (EU) (6GK5856-2EA00-3DA1):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE MUM856-1 (RoW) (6GK5856-2EA00-3AA1):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE S615 family:</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE S615 EEC LAN-Router (6GK5615-0AA01-2AA2):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE S615 LAN-Router (6GK5615-0AA00-2AA2):</p> <p>All versions < V6.4 affected by CVE-2020-28400</p>	<p>Update to V6.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109794349/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE W-700 IEEE 802.11n family:</p>	<p>Currently no fix is planned See recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE W721-1 RJ45 (6GK5721-1FC00-0AA0):</p> <p>All versions affected by CVE-2020-28400</p>	<p>Currently no fix is planned See recommendations from section Workarounds and Mitigations</p>

SCALANCE W721-1 RJ45 (6GK5721-1FC00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W722-1 RJ45 (6GK5722-1FC00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W722-1 RJ45 (6GK5722-1FC00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W722-1 RJ45 (6GK5722-1FC00-0AC0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W734-1 RJ45 (6GK5734-1FX00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W734-1 RJ45 (6GK5734-1FX00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W734-1 RJ45 (6GK5734-1FX00-0AA6): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W734-1 RJ45 (USA) (6GK5734-1FX00-0AB6): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W738-1 M12 (6GK5738-1GY00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W738-1 M12 (6GK5738-1GY00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W748-1 M12 (6GK5748-1GD00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W748-1 M12 (6GK5748-1GD00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations

SCALANCE W748-1 RJ45 (6GK5748-1FC00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W748-1 RJ45 (6GK5748-1FC00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W761-1 RJ45 (6GK5761-1FC00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W761-1 RJ45 (6GK5761-1FC00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W774-1 M12 EEC (6GK5774-1FY00-0TA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W774-1 M12 EEC (6GK5774-1FY00-0TB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W774-1 RJ45 (6GK5774-1FX00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W774-1 RJ45 (6GK5774-1FX00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W774-1 RJ45 (6GK5774-1FX00-0AC0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W774-1 RJ45 (6GK5774-1FX00-0AA6): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W774-1 RJ45 (USA) (6GK5774-1FX00-0AB6): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W778-1 M12 (6GK5778-1GY00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations

SCALANCE W778-1 M12 (6GK5778-1GY00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W778-1 M12 EEC (6GK5778-1GY00-0TA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W778-1 M12 EEC (USA) (6GK5778-1GY00-0TB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W786-1 RJ45 (6GK5786-1FC00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W786-1 RJ45 (6GK5786-1FC00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W786-2 RJ45 (6GK5786-2FC00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W786-2 RJ45 (6GK5786-2FC00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W786-2 RJ45 (6GK5786-2FC00-0AC0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W786-2 SFP (6GK5786-2FE00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W786-2 SFP (6GK5786-2FE00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W786-2IA RJ45 (6GK5786-2HC00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W786-2IA RJ45 (6GK5786-2HC00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations

SCALANCE W788-1 M12 (6GK5788-1GD00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W788-1 M12 (6GK5788-1GD00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W788-1 RJ45 (6GK5788-1FC00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W788-1 RJ45 (6GK5788-1FC00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W788-2 M12 (6GK5788-2GD00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W788-2 M12 (6GK5788-2GD00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W788-2 M12 EEC (6GK5788-2GD00-0TA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W788-2 M12 EEC (6GK5788-2GD00-0TB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W788-2 M12 EEC (6GK5788-2GD00-0TC0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W788-2 RJ45 (6GK5788-2FC00-0AA0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W788-2 RJ45 (6GK5788-2FC00-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SCALANCE W788-2 RJ45 (6GK5788-2FC00-0AC0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations

SCALANCE W-1700 IEEE 802.11ac family:	Update to V3.0.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109808629/ See further recommendations from section Workarounds and Mitigations
SCALANCE W1748-1 M12 (6GK5748-1GY01-0TA0): All versions < V3.0.0 affected by CVE-2020-28400	Update to V3.0.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109808629/ See further recommendations from section Workarounds and Mitigations
SCALANCE W1748-1 M12 (6GK5748-1GY01-0AA0): All versions < V3.0.0 affected by CVE-2020-28400	Update to V3.0.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109808629/ See further recommendations from section Workarounds and Mitigations
SCALANCE W1788-1 M12 (6GK5788-1GY01-0AA0): All versions < V3.0.0 affected by CVE-2020-28400	Update to V3.0.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109808629/ See further recommendations from section Workarounds and Mitigations
SCALANCE W1788-2 EEC M12 (6GK5788-2GY01-0TA0): All versions < V3.0.0 affected by CVE-2020-28400	Update to V3.0.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109808629/ See further recommendations from section Workarounds and Mitigations
SCALANCE W1788-2 M12 (6GK5788-2GY01-0AA0): All versions < V3.0.0 affected by CVE-2020-28400	Update to V3.0.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109808629/ See further recommendations from section Workarounds and Mitigations
SCALANCE W1788-2IA M12 (6GK5788-2HY01-0AA0): All versions < V3.0.0 affected by CVE-2020-28400	Update to V3.0.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109808629/ See further recommendations from section Workarounds and Mitigations
SCALANCE X-200 family (incl. SIPLUS NET variants):	Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations

<p>SCALANCE X204-2 (6GK5204-2BB10-2AA3): All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X204-2FM (6GK5204-2BB11-2AA3): All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X204-2LD (6GK5204-2BC10-2AA3): All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X204-2LD TS (6GK5204-2BC10-2CA2): All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X204-2TS (6GK5204-2BB10-2CA2): All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X206-1 (6GK5206-1BB10-2AA3): All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X206-1LD (6GK5206-1BC10-2AA3): All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X208 (6GK5208-0BA10-2AA3): All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE X208PRO (6GK5208-0HA10-2AA6):</p> <p>All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X212-2 (6GK5212-2BB00-2AA3):</p> <p>All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X212-2LD (6GK5212-2BC00-2AA3):</p> <p>All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X216 (6GK5216-0BA00-2AA3):</p> <p>All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X224 (6GK5224-0BA00-2AA3):</p> <p>All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XF204 (6GK5204-0BA00-2AF2):</p> <p>All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XF204-2 (6GK5204-2BC00-2AF2):</p> <p>All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XF206-1 (6GK5206-1BC00-2AF2):</p> <p>All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE XF208 (6GK5208-0BA00-2AF2): All versions < V5.2.5 affected by CVE-2020-28400</p>	<p>Update to V5.2.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109801131/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X-200IRT family (incl. SIPLUS NET variants):</p>	<p>Update to V5.5.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109793952/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X200-4P IRT (6GK5200-4AH00-2BA3): All Versions < V5.5.0 affected by CVE-2020-28400</p>	<p>Update to V5.5.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109793952/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X201-3P IRT (6GK5201-3BH00-2BA3): All Versions < V5.5.0 affected by CVE-2020-28400</p>	<p>Update to V5.5.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109793952/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X201-3P IRT PRO (6GK5201-3JR00-2BA6): All Versions < V5.5.0 affected by CVE-2020-28400</p>	<p>Update to V5.5.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109793952/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X202-2IRT (6GK5202-2BB00-2BA3): All Versions < V5.5.0 affected by CVE-2020-28400</p>	<p>Update to V5.5.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109793952/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X202-2P IRT (6GK5202-2BH00-2BA3): All Versions < V5.5.0 affected by CVE-2020-28400</p>	<p>Update to V5.5.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109793952/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X202-2P IRT PRO (6GK5202-2JR00-2BA6): All Versions < V5.5.0 affected by CVE-2020-28400</p>	<p>Update to V5.5.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109793952/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE X204IRT (6GK5204-0BA00-2BA3):</p> <p>All Versions < V5.5.0 affected by CVE-2020-28400</p>	<p>Update to V5.5.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109793952/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X204IRT PRO (6GK5204-0JA00-2BA6):</p> <p>All Versions < V5.5.0 affected by CVE-2020-28400</p>	<p>Update to V5.5.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109793952/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XF201-3P IRT (6GK5201-3BH00-2BD2):</p> <p>All Versions < V5.5.0 affected by CVE-2020-28400</p>	<p>Update to V5.5.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109793952/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XF202-2P IRT (6GK5202-2BH00-2BD2):</p> <p>All Versions < V5.5.0 affected by CVE-2020-28400</p>	<p>Update to V5.5.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109793952/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XF204-2BA IRT (6GK5204-2AA00-2BD2):</p> <p>All Versions < V5.5.0 affected by CVE-2020-28400</p>	<p>Update to V5.5.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109793952/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XF204IRT (6GK5204-0BA00-2BF2):</p> <p>All Versions < V5.5.0 affected by CVE-2020-28400</p>	<p>Update to V5.5.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109793952/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X-300 family (incl. X408 and SIPLUS NET variants):</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X-300 EEC family:</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE X302-7 EEC (230V, coated) (6GK5302-7GD00-3GA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X302-7 EEC (230V) (6GK5302-7GD00-3EA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X302-7 EEC (24V, coated) (6GK5302-7GD00-1GA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X302-7 EEC (24V) (6GK5302-7GD00-1EA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X302-7 EEC (2x 230V, coated) (6GK5302-7GD00-4GA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X302-7 EEC (2x 230V) (6GK5302-7GD00-4EA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X302-7 EEC (2x 24V, coated) (6GK5302-7GD00-2GA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X302-7 EEC (2x 24V) (6GK5302-7GD00-2EA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE X307-2 EEC (230V, coated) (6GK5307-2FD00-3GA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X307-2 EEC (230V) (6GK5307-2FD00-3EA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X307-2 EEC (24V, coated) (6GK5307-2FD00-1GA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X307-2 EEC (24V) (6GK5307-2FD00-1EA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X307-2 EEC (2x 230V, coated) (6GK5307-2FD00-4GA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X307-2 EEC (2x 230V) (6GK5307-2FD00-4EA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X307-2 EEC (2x 24V, coated) (6GK5307-2FD00-2GA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X307-2 EEC (2x 24V) (6GK5307-2FD00-2EA3): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>

SCALANCE X-300 family:	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations
SCALANCE X304-2FE (6GK5304-2BD00-2AA3): All versions < V4.1.4 affected by CVE-2020-28400	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations
SCALANCE X306-1LD FE (6GK5306-1BF00-2AA3): All versions < V4.1.4 affected by CVE-2020-28400	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations
SCALANCE X320-1 FE (6GK5320-1BD00-2AA3): All versions < V4.1.4 affected by CVE-2020-28400	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations
SCALANCE X320-1-2LD FE (6GK5320-3BF00-2AA3): All versions < V4.1.4 affected by CVE-2020-28400	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations
SCALANCE X300 family:	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations
SCALANCE X307-3 (6GK5307-3BL00-2AA3): All versions < V4.1.4 affected by CVE-2020-28400	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations
SCALANCE X307-3LD (6GK5307-3BM00-2AA3): All versions < V4.1.4 affected by CVE-2020-28400	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations

<p>SCALANCE X308-2 (6GK5308-2FL00-2AA3):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X308-2LD (6GK5308-2FM00-2AA3):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X308-2LH (6GK5308-2FN00-2AA3):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X308-2LH+ (6GK5308-2FP00-2AA3):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X310 (6GK5310-0FA00-2AA3):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X310FE (6GK5310-0BA00-2AA3):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X-300 RD family:</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X307-3 (6GK5307-3BL10-2AA3):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE X307-3LD (6GK5307-3BM10-2AA3):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X308-2 RD (inkl. SIPLUS variants):</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X308-2 (6GK5308-2FL10-2AA3):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SIPLUS NET SCALANCE X308-2 (6AG1308-2FL10-4AA3):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X308-2LD (6GK5308-2FM10-2AA3):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X308-2LH (6GK5308-2FN10-2AA3):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X308-2LH+ (6GK5308-2FP10-2AA3):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X310 (6GK5310-0FA10-2AA3):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE X310FE (6GK5310-0BA10-2AA3):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X308-2M family:</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X308-2M (6GK5308-2GG00-2AA2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X308-2M PoE (6GK5308-2QG00-2AA2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X308-2M TS (6GK5308-2GG00-2CA2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X308-2M RD family:</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X308-2M (6GK5308-2GG10-2AA2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X308-2M PoE (6GK5308-2QG10-2AA2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE X308-2M TS (6GK5308-2GG10-2CA2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X408 family:</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE X408-2 (6GK5408-2FD00-2AA2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR-300 family:</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-12M (230V, ports on front) (6GK5324-0GG00-3AR2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-12M (230V, ports on rear) (6GK5324-0GG00-3HR2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-12M (24V, ports on front) (6GK5324-0GG00-1AR2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-12M (24V, ports on rear) (6GK5324-0GG00-1HR2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE XR324-12M TS (24V) (6GK5324-0GG00-1CR2): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR-300 RD family:</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-12M (230V, ports on front) (6GK5324-0GG10-3AR2): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-12M (230V, ports on rear) (6GK5324-0GG10-3HR2): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-12M (24V, ports on front) (6GK5324-0GG10-1AR2): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-12M (24V, ports on rear) (6GK5324-0GG10-1HR2): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-12M TS (24V) (6GK5324-0GG10-1CR2): All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR-300 EEC family:</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE XR324-4M EEC (100-240VAC/60-250VDC, ports on front) (6GK5324-4GG00-3ER2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-4M EEC (100-240VAC/60-250VDC, ports on rear) (6GK5324-4GG00-3JR2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-4M EEC (24V, ports on front) (6GK5324-4GG00-1ER2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-4M EEC (24V, ports on rear) (6GK5324-4GG00-1JR2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-4M EEC (2x 100-240VAC/60-250VDC, ports on front) (6GK5324-4GG00-4ER2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-4M EEC (2x 100-240VAC/60-250VDC, ports on rear) (6GK5324-4GG00-4JR2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-4M EEC (2x 24V, ports on front) (6GK5324-4GG00-2ER2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-4M EEC (2x 24V, ports on rear) (6GK5324-4GG00-2JR2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>

SCALANCE XR-300 EEC RD family:	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations
SCALANCE XR324-4M EEC (100-240VAC/60-250VDC, ports on front) (6GK5324-4GG10-3ER2): All versions < V4.1.4 affected by CVE-2020-28400	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations
SCALANCE XR324-4M EEC (100-240VAC/60-250VDC, ports on rear) (6GK5324-4GG10-3JR2): All versions < V4.1.4 affected by CVE-2020-28400	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations
SCALANCE XR324-4M EEC (24V, ports on front) (6GK5324-4GG10-1ER2): All versions < V4.1.4 affected by CVE-2020-28400	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations
SCALANCE XR324-4M EEC (24V, ports on rear) (6GK5324-4GG10-1JR2): All versions < V4.1.4 affected by CVE-2020-28400	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations
SCALANCE XR324-4M EEC (2x 100-240VAC/60-250VDC, ports on front) (6GK5324-4GG10-4ER2): All versions < V4.1.4 affected by CVE-2020-28400	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations
SCALANCE XR324-4M EEC (2x 100-240VAC/60-250VDC, ports on rear) (6GK5324-4GG10-4JR2): All versions < V4.1.4 affected by CVE-2020-28400	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations
SCALANCE XR324-4M EEC (2x 24V, ports on front) (6GK5324-4GG10-2ER2): All versions < V4.1.4 affected by CVE-2020-28400	Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations

<p>SCALANCE XR324-4M EEC (2x 24V, ports on rear) (6GK5324-4GG10-2JR2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR-300 POE family:</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-4M PoE (230V, ports on front) (6GK5324-4QG00-3AR2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-4M PoE (230V, ports on rear) (6GK5324-4QG00-3HR2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-4M PoE (24V, ports on front) (6GK5324-4QG00-1AR2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-4M PoE (24V, ports on rear) (6GK5324-4QG00-1HR2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324-4M PoE TS (24V, ports on front) (6GK5324-4QG00-1CR2):</p> <p>All versions < V4.1.4 affected by CVE-2020-28400</p>	<p>Update to V4.1.4 or later version https://support.industry.siemens.com/cs/ww/en/view/109808359/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XB-200/XC-200/XP-200/XF-200BA/XR-300WG family:</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>

SCALANCE XB-200 family:	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XB205-3 (SC, PN) (6GK5205-3BB00-2AB2): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XB205-3 (ST, E/IP) (6GK5205-3BD00-2TB2): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XB205-3 (ST, E/IP) (6GK5205-3BB00-2TB2): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XB205-3 (ST, PN) (6GK5205-3BD00-2AB2): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XB205-3LD (SC, E/IP) (6GK5205-3BF00-2TB2): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XB205-3LD (SC, PN) (6GK5205-3BF00-2AB2): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XB208 (E/IP) (6GK5208-0BA00-2TB2): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations

<p>SCALANCE XB208 (PN) (6GK5208-0BA00-2AB2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XB213-3 (SC, E/IP) (6GK5213-3BD00-2TB2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XB213-3 (SC, PN) (6GK5213-3BD00-2AB2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XB213-3 (ST, E/IP) (6GK5213-3BB00-2TB2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XB213-3 (ST, PN) (6GK5213-3BB00-2AB2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XB213-3LD (SC, E/IP) (6GK5213-3BF00-2TB2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XB213-3LD (SC, PN) (6GK5213-3BF00-2AB2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XB216 (E/IP) (6GK5216-0BA00-2TB2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE XB216 (PN) (6GK5216-0BA00-2AB2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC-200 family:</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC206-2 (SC) (6GK5206-2BD00-2AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC206-2 (ST/BFOC) (6GK5206-2BB00-2AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC206-2G PoE (6GK5206-2RS00-2AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC206-2G PoE (54 V DC) (6GK5206-2RS00-5AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC206-2G PoE EEC (54 V DC) (6GK5206-2RS00-5FC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC206-2SFP (6GK5206-2BS00-2AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE XC206-2SFP EEC (6GK5206-2BS00-2FC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC206-2SFP G (6GK5206-2GS00-2AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC206-2SFP G (EIP DEF.) (6GK5206-2GS00-2TC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC206-2SFP G EEC (6GK5206-2GS00-2FC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC208 (6GK5208-0BA00-2AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC208EEC (6GK5208-0BA00-2FC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC208G (6GK5208-0GA00-2AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC208G (EIP def.) (6GK5208-0GA00-2TC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE XC208G EEC (6GK5208-0GA00-2FC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/</p> <p>See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC208G PoE (6GK5208-0RA00-2AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/</p> <p>See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC208G PoE (54 V DC) (6GK5208-0RA00-5AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/</p> <p>See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC216 (6GK5216-0BA00-2AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/</p> <p>See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC216-3G PoE (6GK5216-3RS00-2AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/</p> <p>See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC216-3G PoE (54 V DC) (6GK5216-3RS00-5AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/</p> <p>See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC216-4C (6GK5216-4BS00-2AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/</p> <p>See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC216-4C G (6GK5216-4GS00-2AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/</p> <p>See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE XC216-4C G (EIP Def.) (6GK5216-4GS00-2TC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC216-4C G EEC (6GK5216-4GS00-2FC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC216EEC (6GK5216-0BA00-2FC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC224 (6GK5224-0BA00-2AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC224-4C G (6GK5224-4GS00-2AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC224-4C G (EIP Def.) (6GK5224-4GS00-2TC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XC224-4C G EEC (6GK5224-4GS00-2FC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SIPLUS NET SCALANCE XC206-2 (6AG1206-2BB00-7AC2):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>

SIPLUS NET SCALANCE XC206-2SFP (6AG1206-2BS00-7AC2): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SIPLUS NET SCALANCE XC208 (6AG1208-0BA00-7AC2): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SIPLUS NET SCALANCE XC216-4C (6AG1216-4BS00-7AC2): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XF-200BA family:	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XF204 (6GK5204-0BA00-2GF2): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XF204 DNA (6GK5204-0BA00-2YF2): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XF204-2BA (6GK5204-2AA00-2GF2): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XF204-2BA DNA (6GK5204-2AA00-2YF2): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations

SCALANCE XP-200 family:	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XP208 (6GK5208-0HA00-2AS6): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XP208 (Ethernet/IP) (6GK5208-0HA00-2TS6): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XP208EEC (6GK5208-0HA00-2ES6): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XP208PoE EEC (6GK5208-0UA00-5ES6): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XP216 (6GK5216-0HA00-2AS6): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XP216 (Ethernet/IP) (6GK5216-0HA00-2TS6): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations
SCALANCE XP216EEC (6GK5216-0HA00-2ES6): All versions < V4.3 affected by CVE-2020-28400	Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations

<p>SCALANCE XP216POE EEC (6GK5216-0UA00-5ES6):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR-300WG family:</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324WG (24 x FE, AC 230V) (6GK5324-0BA00-3AR3):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR324WG (24 X FE, DC 24V) (6GK5324-0BA00-2AR3):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR326-2C PoE WG (6GK5326-2QS00-3AR3):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR326-2C PoE WG (without UL) (6GK5326-2QS00-3RR3):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR328-4C WG (24XFE, 4XGE, 24V) (6GK5328-4FS00-2AR3):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR328-4C WG (24xFE, 4xGE, DC24V) (6GK5328-4FS00-2RR3):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE XR328-4C WG (24xFE,4xGE,AC230V) (6GK5328-4FS00-3AR3):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR328-4C WG (24xFE,4xGE,AC230V) (6GK5328-4FS00-3RR3):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR328-4C WG (28xGE, AC 230V) (6GK5328-4SS00-3AR3):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR328-4C WG (28xGE, DC 24V) (6GK5328-4SS00-2AR3):</p> <p>All versions < V4.3 affected by CVE-2020-28400</p>	<p>Update to V4.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109799569/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XM-400/XR-500 family:</p>	<p>See below See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XM-400 family:</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782067/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XM408-4C (6GK5408-4GP00-2AM2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782067/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XM408-4C (L3 int.) (6GK5408-4GQ00-2AM2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782067/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XM408-8C (6GK5408-8GS00-2AM2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782067/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE XM408-8C (L3 int.) (6GK5408-8GR00-2AM2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782067/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XM416-4C (6GK5416-4GS00-2AM2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782067/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XM416-4C (L3 int.) (6GK5416-4GR00-2AM2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782067/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR-500 family:</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR524-8C, 1x230V (6GK5524-8GS00-3AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR524-8C, 1x230V (L3 int.) (6GK5524-8GR00-3AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR524-8C, 24V (6GK5524-8GS00-2AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR524-8C, 24V (L3 int.) (6GK5524-8GR00-2AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE XR524-8C, 2x230V (6GK5524-8GS00-4AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR524-8C, 2x230V (L3 int.) (6GK5524-8GR00-4AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR526-8C, 1x230V (6GK5526-8GS00-3AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR526-8C, 1x230V (L3 int.) (6GK5526-8GR00-3AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR526-8C, 24V (6GK5526-8GS00-2AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR526-8C, 24V (L3 int.) (6GK5526-8GR00-2AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR526-8C, 2x230V (6GK5526-8GS00-4AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR526-8C, 2x230V (L3 int.) (6GK5526-8GR00-4AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>

<p>SCALANCE XR528-6M (6GK5528-0AA00-2AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR528-6M (2HR2, L3 int.) (6GK5528-0AR00-2HR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR528-6M (2HR2) (6GK5528-0AA00-2HR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR528-6M (L3 int.) (6GK5528-0AR00-2AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR552-12M (6GK5552-0AA00-2AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR552-12M (2HR2, L3 int.) (6GK5552-0AR00-2AR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR552-12M (2HR2) (6GK5552-0AA00-2HR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>
<p>SCALANCE XR552-12M (2HR2) (6GK5552-0AR00-2HR2):</p> <p>All versions < V6.3.1 affected by CVE-2020-28400</p>	<p>Update to V6.3.1 or later version https://support.industry.siemens.com/cs/ww/en/view/109782065/ See further recommendations from section Workarounds and Mitigations</p>

SIMATIC CFU DIQ (6ES7655-5PX31-1XX0): All versions < V2.0.0 affected by CVE-2020-28400	Update to V2.0.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109781049/ See further recommendations from section Workarounds and Mitigations
SIMATIC CFU PA (6ES7655-5PX11-0XX0): All versions < V2.0.0 affected by CVE-2020-28400	Update to V2.0.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109754628/ See further recommendations from section Workarounds and Mitigations
SIMATIC CM 1542-1: All versions < V3.0 affected by CVE-2020-28400	Update to V3.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109801629/ See further recommendations from section Workarounds and Mitigations
SIMATIC CP 1604 (6GK1160-4AA01): All Versions >= V2.7 affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SIMATIC CP 1616 (6GK1161-6AA02): All Versions >= V2.7 affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SIMATIC CP 1626 (6GK1162-6AA01): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SIMATIC IE/PB-LINK: All versions >= V3 affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SIMATIC MV540 H (6GF3540-0GE10): All versions < V3.0 affected by CVE-2020-28400	Update to V3.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109795469/ See further recommendations from section Workarounds and Mitigations
SIMATIC MV540 S (6GF3540-0CD10): All versions < V3.0 affected by CVE-2020-28400	Update to V3.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109795469/ See further recommendations from section Workarounds and Mitigations
SIMATIC MV550 H (6GF3550-0GE10): All versions < V3.0 affected by CVE-2020-28400	Update to V3.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109795469/ See further recommendations from section Workarounds and Mitigations

SIMATIC MV550 S (6GF3550-0CD10): All versions < V3.0 affected by CVE-2020-28400	Update to V3.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109795469/ See further recommendations from section Workarounds and Mitigations
SIMATIC MV560 U (6GF3560-0LE10): All versions < V3.0 affected by CVE-2020-28400	Update to V3.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109795469/ See further recommendations from section Workarounds and Mitigations
SIMATIC MV560 X (6GF3560-0HE10): All versions < V3.0 affected by CVE-2020-28400	Update to V3.0 or later version https://support.industry.siemens.com/cs/ww/en/view/109795469/ See further recommendations from section Workarounds and Mitigations
SIMATIC NET DK-16xx PN IO: All Versions >= V2.7 affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SIMATIC Power Line Booster PLB, Base Module (6ES7972-5AA10-0AB0): All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
SIMATIC PROFINET Driver: All versions < V2.3 affected by CVE-2020-28400	Update to V2.3 or later version https://support.industry.siemens.com/cs/de/en/view/109802422/ See further recommendations from section Workarounds and Mitigations
SIMATIC S7-1200 CPU family (incl. SIPLUS variants): All Versions < V4.5 affected by CVE-2020-28400	Update to V4.5 or later version https://support.industry.siemens.com/cs/ww/en/view/109793280/ See further recommendations from section Workarounds and Mitigations
SIMOCODE pro V Ethernet/IP (incl. SIPLUS variants): All versions < V1.1.3 affected by CVE-2020-28400	Update to V1.1.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109756912/ See further recommendations from section Workarounds and Mitigations
SIMOCODE pro V PROFINET (incl. SIPLUS variants): All versions < V2.1.3 affected by CVE-2020-28400	Update to V2.1.3 or later version https://support.industry.siemens.com/cs/ww/en/view/109749989/ See further recommendations from section Workarounds and Mitigations

SOFTNET-IE PNIO: All versions affected by CVE-2020-28400	Currently no fix is planned See recommendations from section Workarounds and Mitigations
--	---

WORKAROUNDS AND MITIGATIONS

Siemens has identified the following specific workarounds and mitigations that customers can apply to reduce the risk:

- Block incoming Profinet Discovery and Configuration Protocol (DCP) packets (Ethertype 0x8892, Frame-ID: 0xfefe) from untrusted networks
- Disable Profinet in products, where Profinet is optional and not used in your environment

Product-specific remediations or mitigations can be found in the section [Affected Products and Solution](#). Please follow the [General Security Recommendations](#).

GENERAL SECURITY RECOMMENDATIONS

As a general security measure, Siemens strongly recommends to protect network access to devices with appropriate mechanisms. In order to operate the devices in a protected IT environment, Siemens recommends to configure the environment according to Siemens' operational guidelines for Industrial Security (Download: <https://www.siemens.com/cert/operational-guidelines-industrial-security>), and to follow the recommendations in the product manuals. Additional information on Industrial Security by Siemens can be found at: <https://www.siemens.com/industrialsecurity>

PRODUCT DESCRIPTION

SIMATIC CP 1616 and CP 1604 are PCI/PCI-104 cards for high-performance connection of field devices to Industrial Ethernet with PROFINET.

SIMATIC CP 1623, CP 1626 and CP 1628 are PCI express cards for connection to Industrial Ethernet.

SIMATIC CP 1626 are PCI express cards for connecting field devices to Industrial Ethernet with PROFINET.

Development/Evaluation Kits for PROFINET IO are used to develop compact or modular PROFINET field devices.

SIMATIC IE/PB-Link devices enable existing PROFIBUS devices to be integrated into a PROFINET application.

RUGGEDCOM RM1224 is a 4G ROUTER for wireless IP-communication from Ethernet based devices via LTE(4G)- mobile radio.

SCALANCE M-800, MUM-800 and S615 as well as the RUGGEDCOM RM1224 are industrial routers.

SCALANCE W products are wireless communication devices used to connect industrial components, like Programmable Logic Controllers (PLCs) or Human Machine Interfaces (HMIs), according to the IEEE 802.11 standard (802.11ac, 802.11a/b/g/h, and/or 802.11n).

SCALANCE W-1700 products are wireless communication devices based on IEEE 802.11ac standard. They are used to connect all to sorts of WLAN devices (Access Points or Clients, depending on the operating mode) with a strong focus on industrial components, like Programmable Logic Controllers (PLCs) or Human Machine Interfaces (HMIs) and others.

SCALANCE W-700 products are wireless communication devices based on IEEE 802.11ax or 802.11n standard. They are used to connect all to sorts of WLAN devices (Access Points or Clients, depending on the operating mode) with a strong focus on industrial components, like Programmable Logic Controllers (PLCs) or Human Machine Interfaces (HMIs) and others.

SCALANCE X switches are used to connect industrial components like Programmable Logic Controllers (PLCs) or Human Machine Interfaces (HMIs).

SIMATIC Compact Field Unit (SIMATIC CFU) is a smart field distributor for use as an I/O device on PROFINET of an automation system.

The SIMATIC CM 1542-1 communication module is used to connect S7-1500 controllers to PROFINET as IO-Controller.

The Development Kit DK-16xx PN IO permits an easy integration of CP 1616 and CP 1604 in non-Windows operating system environments.

SIMATIC MV500 products are stationary optical readers, used to reliably capture printed, lasered, drilled, punched and dotpeen codes on a variety of different surfaces.

PROFINET Driver is a development kit used to develop PROFINET IO controllers.

The SIMATIC Power Line Booster system is a communication system for data transmission on conductive media.

SIMATIC S7-300, S7-400, S7-1200 CPU and S7-1500 CPU controllers have been designed for discrete and continuous control in industrial environments such as manufacturing, food and beverages, and chemical industries worldwide.

SIMOCODE pro is a modular motor management system that combines all required protection, monitoring, safety and control functions for motor feeders.

With the SINAMICS converter series you can solve drive tasks in the low, medium and DC voltage range.

SINUMERIK CNC offers automation solutions for the shop floor, job shops and large serial production environments.

SIPLUS extreme products are designed for reliable operation under extreme conditions and are based on SIMATIC, LOGO!, SITOP, SINAMICS, SIMOTION, SCALANCE or other devices. SIPLUS devices use the same firmware as the product they are based on.

The SIPLUS HCS 4x00 heating control system is used to control and switch heaters in industry control und operation e.g. quartz, ceramic, flash, halogen or infrared heaters.

The SOFTNET product family includes several software applications for connecting programming devices to Industrial Ethernet and PROFIBUS.

VULNERABILITY DESCRIPTION

This chapter describes all vulnerabilities (CVE-IDs) addressed in this security advisory. Wherever applicable, it also documents the product-specific impact of the individual vulnerabilities.

Vulnerability CVE-2020-28400

Affected devices contain a vulnerability that allows an unauthenticated attacker to trigger a denial of service condition. The vulnerability can be triggered if a large amount of DCP reset packets are sent to the device.

CVSS v3.1 Base Score	7.5
CVSS Vector	CVSS:3.1/AV:N/AC:L/PR:N/UI:N/S:U/C:N/I:N/A:H
CVSS v4.0 Base Score	8.7
CVSS Vector	CVSS:4.0/AV:N/AC:L/AT:N/PR:N/UI:N/VC:N/VI:N/VA:H/SC:N/SI:N/SA:N
CWE	CWE-770: Allocation of Resources Without Limits or Throttling

ADDITIONAL INFORMATION

For further inquiries on security vulnerabilities in Siemens products and solutions, please contact the Siemens ProductCERT:

<https://www.siemens.com/cert/advisories>

HISTORY DATA

V1.0 (2021-07-13):	Publication Date
V1.1 (2021-08-10):	Added solution for SCALANCE XR-300WG, SCALANCE XB-200, SCALANCE XP-200, SCALANCE XC-200, SCALANCE XF-200 and EK-ERTEC 200P
V1.2 (2021-09-14):	Added solution for SCALANCE X-200 switch family and SIMATIC NET CM 1542-1
V1.3 (2021-10-12):	Added solution for SIMATIC PROFINET Driver
V1.4 (2022-02-08):	Clarified that no remediation is planned for SCALANCE W700 and SCALANCE W1700, SIMATIC CP 1604, SIMATIC CP 1616, and SIMATIC CP 1626
V1.5 (2022-04-12):	Added solution for SCALANCE X-300 switch family (incl. X408 and SIPLUS NET variants) and SCALANCE W-1700 (11ac) family
V1.6 (2024-06-11):	Added fix for SIMATIC CFU PA/DIQ; fix planned for SIMATIC IE/PB-LINK
V1.7 (2024-11-12):	Added fix for SCALANCE XR-300WG family (was no longer listed since V1.5 of the SSA); consolidated and expanded list of affected SCALANCE product families, incl. MLFB information
V1.8 (2024-12-10):	Clarified that no fix is planned for SIMATIC IE/PB-LINK; Added CVSSv4.0 vector

TERMS OF USE

The use of Siemens Security Advisories is subject to the terms and conditions listed on: <https://www.siemens.com/productcert/terms-of-use>.